



ROTALIGN Ultra iS Live Trend


Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Саратов (845)249-38-78	Ярославль (4852)69-52-93

ROTALIGN® Ultra Live Trend

Real-time measurement of machine positional change



- Simultaneous monitoring of vertical and horizontal machine displacement
- Continuous monitoring of thermal growth during run-up or coast-down phase
- No need to adjust components during measurement and running of machines
- Suitable brackets for different type of machines

ROTALIGN® Ultra

Live Trend add-on module

Cold alignment targets may not accurately predict the actual operating condition of a running machine. Live Trend is used to monitor movement of machines during run-up or coast-down phase, in order to determine the positional change over time and the influences of given events.



Running on the
ROTALIGN® Ultra Shaft
Expert platform, machine
positional changes are
monitored in real time

Highlights

- ▶ Continuous measurement of machine displacement
- ▶ Accurate measurement of the actual thermal target values
- ▶ Live display of horizontal and vertical coupling and feet values
- ▶ Trend plot of horizontal and vertical coupling and feet values
- ▶ Video replay of machine positional change
- ▶ Flexible selection of markers to indicate events during measurement
- ▶ Ability to import machine settings from the shaft alignment program
- ▶ RF module for wireless data transmission between measurement sensor and computer
- ▶ The unique single laser makes set-up adjustment fast and easy
- ▶ Industrial protection IP 65 and IP 67
- ▶ Flexible bracket configuration

This add-on module runs on the ROTALIGN® Ultra platform and utilizes the ROTALIGN® or sensALIGN™ sensors to monitor continuously, in real-time and simultaneously both the vertical and horizontal parallel and angular displacement of rotating machinery, from cold to hot condition or vice versa and hence determining the relative positional change between coupled machines during operation.



Available in two
different bracket
configurations
for magnetic or
screwed-on fixation

Reliability starts with precision alignment

The biggest contribution one can make to lower the operating costs of rotating systems is to align them correctly using the real coupling target values.

Target values recommended by manufacturers do not always reflect the real thermal growth compensation values and dynamic factors. Live Trend application helps to exactly determine the actual positional changes during run-up or coast-down phases.

By applying these values, the machines are precisely aligned to reflect normal operating conditions.

This means:

- ▶ Lower energy costs through reduced power consumption
- ▶ Increased mechanical life of bearings, seals, shafts and couplings
- ▶ Reduced bearing and coupling temperatures
- ▶ Minimized breaking or cracking of shafts
- ▶ Reduced vibration
- ▶ Reduced machine damage



По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Саратов (845)249-38-78	Ярославль (4852)69-52-93